

# HENLEY™ SEATING

## Operating Instructions High-Back and Mid-Back Models



P.O. Box 8400  
Green Bay, WI 54308-8400  
Tel 920.468.8100 • Fax 920.468.2633  
©OEI 2005 Litho in USA Code OE-60878/VL205

## Deriving Maximum Benefits From Your Henley Chair

### A. Seat Height Adjustment

Pull the seat lever up, toward seat, to activate seat height mechanism. To lower the seat, pull up on the lever while sitting. To raise height, sit up slightly off chair while lifting the lever. Release lever to lock in place.

### B. Seat Depth MIDBACK MODEL ONLY

The hand wheel located on the underside of the mechanism allows the back to be adjusted horizontally. With hand wheel loosened, back can be slid forward or backward to change seat depth. Use care to make sure hand wheel is tightened to avoid injury.

### C. Back Tension HIBACK MODEL ONLY

Turn the mechanism hand wheel clockwise to tighten back tension and counterclockwise to loosen back tension. (Not Shown)

### D. Lumbar Adjustment

Loosen hand wheel located in the center of the back support. Slide back support up or down to desired height. Tighten hand wheel to hold in place. Use care to make sure hand wheel is tight to avoid injury.

### E. Arm Adjustment

Adjustable arms have a vertical height adjustment. Locate the adjustment knob under the arm cap; pull up or down and release at the desired height.

