

OUTFIT™ SEATING

Operating Instructions

Executive High-Back, Managerial Mid-Back & Stool



P.O. Box 8400 • Green Bay, WI 54308-8400

Tel 920.468.8100 • Fax 920.468.2633

©OEI 2010 Litho in USA Code OE-60896/VL0210

Obtaining Maximum Benefits From Your Outfit™ Executive High-Back OEI59, Managerial Mid-Back OEI58, Managerial Mid-Back OEI57 (with no seat depth), or Stool Option OEI53

A. Headrest (OEI59 Only)

Grasp with both hands and raise or lower to desired position.

B. Back Height Adjustment

To raise the back - grasp the lower edge of the back and raise the back to the desired height.

C. Tilt-Lock Adjustment

Pull out the lever to achieve free-float option; push lever in to one of three lock positions.

D. Seat Height Adjustment

To lower the seat, remain seated in chair and raise the lever. To raise the seat, lift body weight slightly off the chair and raise the lever.

E. Tilt-Tension Adjustment

Turn the knob clockwise to increase tension and counterclockwise to decrease tension.

F. Seat Depth Adjustment (OEI59 & OEI58 only)

Grasp lever on left side of chair. Lift lever and shift weight on seat front-to-back to move to desired position. Release lever.

G. Arm Options

Adjustable Loop Arm-lift button on outside of arm to raise and lower arm. Release to lock in place.

360° Pivoting Arm-raise arm assembly slightly and rotate to desire position. Lower to lock in place. Lift button on outside of arm to raise and lower arm height. Lift button under arm to adjust width. Release buttons to lock in place.

Adjustable Task Arm-lift button on side of arm to raise and lower arm height. Lift button under arm to adjust width. Release buttons to lock in place.

H. Foot Ring Adjustment (OEI53 Only-not shown)

Loosen and tighten the hand knob on the foot ring to raise and lower.

